



UI Tiles – AV Solutions – Multi Text Tile - Cloud version 3.0001.0023

Driver

This release note is for the AV Solutions Multi Text Tile Extension.

Notes and Recommendations

Drivers->UI Tiles->AV Solutions-> Multi Text Tile

System Requirements and Dependencies

- Crestron Home v4.007.0243
- An offline license is required for the driver to operate beyond its 2-hour trial

Introduction

This UI extension driver provides the integrator with the ability to add up to 30 text displays within a single tile. The tile can be typically used to simplify the users experience by preview custom strings.

Key Features

- Flexible Viewing Options: Can be viewed at the room level, on the home page, or both, for intuitive access tailored to user preferences.
- Customization: Supports up to 30 text displays under a single tile with custom labels.

Installation/Upgrade Instructions

Installation Settings

ⓘ License Key

Obtain a license key from <https://mylicensingwebsite.com>. The driver operates in trial mode for 2 hours without a key

Enter License Key Here

ⓘ Display In Home Page

Show The Tile In The Home Page

ⓘ Display In Room

Show This Tile On A Room Level

- License Key: Required for indefinite use; without it, the driver enters a 2-hour trial mode.
- Display In Home Page: Leave checked to show the tile on the home page. Uncheck to hide
- Display In Room: Leave checked to show the tile on a room level. Uncheck to hide

Installation Settings



Instance Name (Required For Multi-Instance)

Enter A UNIQUE Name For This Driver Instance (e.g., 'Kitchen')



Page Main Title

Enter The Main Tile Title



Icon Keys

Icon reference document

<https://sdkcon78...>

- Instance Name: Unique identifier for state persistence. When using this driver multiple times on a processor, assign a unique value to each instance. This value ensures the correct state is loaded from NVRAM after a power loss, if the Persist State To NVRAM option is enabled.
- Main Page Title: Custom Title for the page once tile opens.
- Icon Keys: The link takes you to the website with all the Icon Keys supported by Crestron SDK.

Installation Settings



Tile Icon

Enter The Icon Key For The Tile



Number Of Text Displays

The Quantity Of Text Displays (1-30)



Text Display 1 Title

Enter Title For Text Display 1

- Tile Icon: Enter the desired Icon Key for the tile.
- Number OF Text Displays: Enter the number of text displays to appear inside the tile
- Text Display xx Title: Enter the text tile to be shown on the corresponding text display

Actions & Events

- Actions



<p>Mode Sequence ▾</p> <p>< Multi Text Display</p> <p>+ Txt Display 1 Message</p> <p>+ Txt Display 2 Message</p> <p>+ Txt Display 3 Message</p>	<ul style="list-style-type: none">• Txt Display xx Message: Set the desired message to the corresponding text display
---	---

- No Events

Setup Guide: Device Control and Synchronization

Now that the driver is added and basic parameters are set, you are able configure it to efficiently control other shade devices (e.g., via events and actions)

End-User Experience



Test Environment

- Crestron Home v4.007.0243

Contact Information

- Company: AV Solutions LTD Cyprus
- Author: Stylianos Michael
- Email: driversupport@avsolutionsltd.com
- Website: www.avsdriers.com

Version History

3.0001.0023

11/11/2025

Licensing and Copyright Information

2025 © AV Solutions LTD, all rights reserved